



Determine the type of your BB shell	BB shell frame width	BB model	Fully assembled width	Non-drive side spacer usage	Drive side spacer usage	Use the following crankset
<p>BSA BB-M8000</p>	68mm (Road)		96mm	1 x 2.5mm	2 x 2.5mm	FC-M9050 FC-M8050
	73mm (Mountain)		73mm	✕	1 x 2.5mm	FC-M9050 FC-M8050
	83mm (DH)		111mm	1 x 2.5mm	2 x 2.5mm	FC-M8070